



DDC1-RV0 MOUNTING
TEMPLATE AND NOTES

The switch does not have to be used.
If no switch is desired solder the included
1 ohm resistor across J1 holes.

If no switch is desired the board can be
secured using the large hole in the middle
and the included spacer and hardware.

